Brugervejledning Mono kontorstol User manual Mono office chair

1. udgave





Brugervejledning Mono kontorstol nr. 7104

User manual Mono swivel chair no. 7104



Beskrivelse

Dimensioner: Bredde 642mm Dybde 517mm Højde 984mm sædehøjde 480-600 mm.

- Synkronfunktion,
- net-ryg og stofsæde i antracitgrå,
- sort nylon fodkryds,
- Hjul med bløde baner,
- o Lås: 3 positioner
- Armlæn fast højde varenr. 7105 (tillæg)

Description

Dimensions: Width 642mm Depth 517mm Height 984mm Seat height 480-600 mm.

- Mechanics: synchronous,
- Mesh back/fabric seat: Anthracite grey,
- o Foot rest: Black nylon,
- Castors for hard floor,
- Lock: 3 positions
- o Armrest fixed height item no. 7105 (additional)





Synkron mekanisme Synchronic mechanism

Brugervejledning Mono kontorstol nr. 7104

User manual Mono swivel chair no. 7104



Højderegulering af stol Heightadjustement



Vippe modstand regulering Tilt tension adjustment



Låsning af vip Tilt locking



Sædedybde regulering Seat sliding adjustment





User Manual



1 Height Adjusting Lever

Pull lever up to raise seat height without applying any weights on a chair or pull lever down while seating on a chair to lower seat height.

② Locking Knob (3 Point)


Turn the hand knob counter-clockwise to lock the tilt action.

Turn the hand knob clockwise and give the pressure on backrest to unlock the tilt action.

3 Tilt Tension Adjusting Knob

Turn the hand knob clockwise to harden the tension.

Turn the hand knob counter-clockwise to soften the tension.



4 Adjustable Armrest

Mechanism enabling user to vertically adjust the position of armrest according to preference or work environment.


With angle-adjustable pad on armrests, it helps release tension on the elbow.

⑤ Adjustable Lumbar Support

Pull lumbar support up or down to adjust height.

OFFICE DESIGN BY

DENCON



OFFICE DESIGN BY

CAUTION: Safety Instructions

- This chair is for a single person only.
- This chair is for indoor use only. Do not use this outdoor,



- Do not attempt to tilt chairback excessively.
- It is dangerous to put too much pressure on armrest.
- Do not climb on a chair to avoid any injuries.



- Do not throw or handle this chair recklessly.
- When you put your hand on the underside of chair and armrest, it may cause injuries.
- Do not crawl underneath this chair.
- Do not use tools with sharp edge such as knife.
- Avoid excessive humidity, heat, and pollutants.
- When you disassemble this chair at own will, manufacturer will not take responsibilities for any damages.
- Glide this chair slowly.
- When you operate levers with excessive pressure, it may break.
- Do not grab sharp edges of backrest with your hand.
- Remove any foreign objects on castors regularly.
- Dry weather may cause static electricity.
- Use protective floor mat when use this chair on soft floor.





OFFICE DESIGN BY

DENCON